



writeINFINITY (dry erase paint)

installation instructions

surface preparation

DO NOT STIR, MIX or SHAKE product!

- Step 1** **For new drywall:** prime wall with high-quality commercial water-based paint primer. **For painted walls in good condition:** lightly sand with 150-grit, then clean surface. **For walls needing repair or colour change:** apply a high-quality, commercial water-based primer tinted to desired colour. Install this step using 3/8" nap microfibre roller cover provided.
- Step 2** Inspect surface for any unwanted texture. If present, lightly sand surface to ensure it is as smooth as possible, then clean.

application

DO NOT STIR, MIX or SHAKE product! **Only apply with 3/8" nap microfibre roller cover provided**

- Step 1** Pour contents into painters' tray with fresh clean liner.
- Step 2** Prime or saturate 3/8" nap microfibre roller cover by rolling in product multiple times to allow the roller to absorb material. Note: Alternative roller covers will leave residue or bubbles in the finished coat, voiding the warranty.
- Step 3** Use a vertical zigzag coating method to spread one loaded roller cover approximately 40 sq ft. Starting midway up the wall, move the roller up and down in a vertical zigzag pattern across the 40 sq ft area.
- Step 4** Without reloading the roller cover, reverse direction and continue spreading the coating back to original starting point using a standard up-and-down coating method. Make one more pass in the other direction using the same rolling method to ensure complete coverage and that a solid, level coating has been achieved. It is important to make these multiple passes to ensure uniform coverage and even distribution with no heavy spots, holes, or uneven texture left on the surface. Inspect carefully from all angles to ensure the entire surface is well-coated. Repeat process for additional sections.
- Step 5** Allow 3 days for product to cure prior to use as a writing surface (recommend the use of Expo Bullet or Bold markers and microfibre cloth erasers).

clean up and disposal

- Step 1:** Do not reseal partially used can. Let unused coating harden in open container and dispose of in accordance with existing federal, state, and local environmental control laws.
- Step 2:** Discard all roller covers and tray liners. Do not pour unused coating down the sink or drain. Clean roller frames with standard paint thinner.