

Cork Installation

Care should be taken in the installation of this natural wallcovering: we recommend installation by a professional Paper Hanger.

Adhesive

1. We recommend a clear Non-staining pre-mixed heavyweight adhesive.
2. Apply the paste to the back of the paper, then fold sheet paste to paste (do not crease) allow the paste to the back to become slightly tacky before hanging.
3. Do not add water to the paste, thinning the paste will make it more easily absorbed and could cause the backing to separate from the natural Cork

Trimming

1. We recommend that you create your own precision trimmed edge by trimming the wallcovering on your work table.
2. Trim the edge with a very sharp razor knife changing the table often to avoid tearing the natural cork surface.

Matching

1. Cork wallcoverings are laminated by hand in a random block pattern: although the match in random the best results will be achieved by dropping the blocks so that the joints do not align.

Tips

1. Do not use a seam roller as it may crush the cork
2. do not allow paste or excessive water to stain the front of the wallcovering.
3. Paste, trim and hang one strip at a time.
4. Subtle shading differences between strips tend to sften over time as the wallcovering begins to oxidize.