



writeLITE, writePROLITE, writeGLASS

care and maintenance instructions

product description

This document references WriteLite, WriteProLite and WriteGlass as the “Products”. This suite of products is a unique set of architectural finishes with writable and erasable surfaces that can be used to convert flat interior surfaces into creative, collaborative environments. For product specific information, please refer to the relevant Technical Data Sheet.

important considerations

- Manufacturer’s recommended dry-erase marker is EXPD® Bullet or Bold. Only use recommended dry erase markers for writing on the Product. “Washable” dry erase markers are not recommended.
- If a non-specified marker is accidentally used, wipe it off immediately with an alcohol-based cleaner. Dry erase markers for whiteboard use are most suitable for writing on the film.
- NEVER use permanent markers or felt pens.
- Keep the eraser clean to prevent ink debris from sticking to the film.

initial installation

Upon initial use, the dry erase marker ink may not adhere well to the film. Writing with a recommended dry erase marker and erasing several times will “break-in” the surface.

regular maintenance

It is recommended that all content be erased from the Product with a microfibre cloth or felt eraser as soon as it is no longer needed. When needed, clean the surface with mild soap and water using a soft cloth. If marker residue is still apparent, use an alcohol based cleaning product.

Projection-capable matte Write ProLite may require more frequent cleaning than glossy versions.